




KEYLESS360 MANAGER INSTRUCTIONS

1. Insert the code retrieval key and turn the knob to .
2. With each dial: spin until it stops. After setting both dials, the last used code will display.
3. Turn the knob back to  and remove the key. Then return the knob to  and scramble the dials for the next user.



See how it works:



KEYLESS360.CO

Notice: Please do not bring valuables into the club. The club is not responsible for loss, theft or damage to a member's or guest's personal property.