




## KEYLESS360 USER INSTRUCTIONS

### TO LOCK

1. Close the door.
2. Make sure knob is pointing up to , then set any 2 digit alphanumeric code.
3. Turn knob to .
4. Scramble the dials.

### TO UNLOCK

1. Re-enter your code.
2. Turn the knob to .
3. Open the door.
4. Scramble the dials for next user.



See how it works:



**KEYLESS360.CO**

Notice: Please do not bring valuables into the club. The club is not responsible for loss, theft or damage to a member's or guest's personal property.